



## MAKE A STREET ADDRESS SIGN

Use this technique to make wood signs for your home or business to indicate address, direction, or entry.

### What you'll need:

|   |   |   |                                     |   |                          |
|---|---|---|-------------------------------------|---|--------------------------|
|  | <b>Dremel EZ SpeedClic:<br/>Finishing<br/>Abrasive Buffs<br/>180&amp;280 grit</b> |  | <b>Finishing<br/>Abrasive Buffs</b> |  | <b>High Speed Cutter</b> |
|---|---|---|-------------------------------------|---|--------------------------|

### Other Supplies:

- 1/2 Plywood Sheet 24"W x 36" H
- Knot-free board
- Wood stain
- Rubber gloves and cloth
- Stencil
- Weather resistant varnish
- Varnish brush
- Outdoor paint and paint brush
- Pencil

## Step by step direction

---



### Step 1

Stain board with your favorite color of wood stain, let dry. Apply layer of varnish over entire sign, let dry. Using a pencil and a template, transfer your street address to the board.



### Step 2

Use the Dremel Stylus and a 191 high speed cutter to carve out the numbers to a uniform depth.



### Step 3

Sand and clean carved areas with 511 abrasive buff.

**Step 4**

Paint address numbers a contrasting color to the wood and let dry.  
Mount as required.